
SIZING INSTRUCTIONS



Coats

1. Chest Size: Measure loosely over clothing around the fullest part of the chest with the arms at rest. Round up measurement to nearest even size.

2. Sleeve length: You should expect that Veridian's standard sleeve length per size would fit a vast majority of fire fighters. Otherwise, with arms straight down to side, measure from the base of the back of the neck, over the shoulder and down the arm to the base of the thumb.

Pants

3. Waist: Measure around waist, over any clothing that would be worn under trousers. Typical men's measurement will be taken just above pant waist, or belt.

4. Inseam: Standard inseam lengths are available in one inch increments. Inseam length should be shorter than regular trouser inseam to prevent damage to cuffs. Measure from the crotch down the inside of the leg to the bottom of the ankle bone.

Sizing Charts (Unit: Inches)

WILDLAND/TECHNICAL RESCUE UTILITY

WL/TRU Pant (MENS)

	SM	MD	LG	XL	2XL	3XL	4XL	5XL	6XL
Waist	26-28	30-32	34-36	38-40	42-44	46-48	50-52	54-56	58-60

WL/TRU Pant (WOMENS)

	XS	SM	MD	LG	XL	2XL	3XL	4XL	5XL
Waist	21-23	25-27	29-31	33-35	37-39	41-43	45-47	49-51	53-55

Inseams available from 24-40 inches in 1 inch increments.
Pant waist is in 2" increments with Alpha Size covering two waist sizes.